

The Yealink CP935W is a wireless IP conference phone designed for VoIP communication. Setting up and using it involves a few steps, from unboxing and connecting it to configuring it for your VoIP service. Here's a step-by-step guide:



1. Unbox and Prepare

- Unbox the phone and ensure all components are included (e.g., power adapter, base unit, cables, and phone).
- Connect the components following the included user manual.

2. Connect the Phone

Wireless Mode

- Connect the CP935W to a wireless network:
 1. Power on the device.
 2. Go to the menu by tapping the touch screen.
 3. Navigate to **Settings > Wi-Fi Settings**.
 4. Enable Wi-Fi, search for your network, and enter the password.

Ethernet Mode (if applicable)

- If you prefer a wired connection, connect an Ethernet cable from the phone's LAN port to your router or network switch.

3. Power On the Phone

- If the phone has a rechargeable battery, ensure it's fully charged.
- Power it on using the designated power button.

4. Configure Handset Features

You need the SIP credentials provided by your VoIP service provider. These typically include:

- SIP Server
- Username
- Password
- Outbound Proxy (optional).

Configure SIP Account:

1. Access the Settings menu on the phone's touchscreen.
2. Go to Account Settings or SIP Settings.
3. Enter the SIP credentials provided by your VoIP service provider.
4. Save the configuration.

Alternatively, you can configure the phone via the Yealink web interface:

1. Find the phone's IP address by going to **Settings > Status**.
2. Open a web browser on your PC and enter the IP address in the address bar.
3. Log in (default username: `admin`, default password: `admin`).
4. Navigate to the Account tab and input the SIP account details.
5. Save and reboot the phone.

5. Test the Connection

- **Make a test call** to ensure the phone is registered and working correctly.
- **Check the Status menu** to confirm the phone is registered with your VoIP service.

6. Use the Phone

Key Features:

- **Place Calls:** Tap the screen, enter the number, and press the Call button.
- **Join Conference:** Use the conference button to connect multiple callers.
- **Mute/Unmute:** Tap the mute button during a call.
- **Access Voicemail:** Follow your VoIP provider's instructions to access voicemail.

Advanced Features:

- **Pair the CP935W** with other devices via Bluetooth or DECT for additional connectivity options.

7. Troubleshooting

Key Features:

- **No Network Connection:** Check Wi-Fi settings or Ethernet connection.
- **Registration Failed:** Verify SIP credentials with your VoIP provider.
- **Audio Issues:** Check volume settings, network quality, or replace cables if using Ethernet.